

M22 AUTOMATIC CHEMICAL AGENT ALARM (ACADA)
HOT WEATHER/DESERT OPERATION

This abbreviated checklist is not to be used as a replacement for the -10 series Tech Manuals or any other PMCS guide

FM 90-3, DESERT OPERATIONS contains detailed instructions for living and working in the desert. TM 3-6665-321-12&P contains detailed PMCS instructions for proper maintenance and operation.

1. When operating the M88 detector in rain, damp or dusty conditions, the M88 detector must be fitted with rain caps and the M88 detector must be in the upright position with the nozzles uppermost at all times.
2. Locate the two rain caps in the pocket of the transit case lid.
3. Gently push the center of each rain cap onto the inlet and exhaust ports.
4. Remove the inlet rain cap whenever the Confidence Sample Test has to be done and leave it off only long enough to apply stimulant from the Confidence Sample.
5. Reinstall the inlet rain cap.