

GTA# 43-01-048

OPERATE CBPS AND FDECU
HOT WEATHER/DESERT OPERATION

This abbreviated checklist is not to be used as a replacement for the -10 series Tech Manuals or any other PMCS guide

CHEMICAL BIOLOGICAL PROTECTIVE SHELTER (CBPS) Monitor Expanded Capacity Vehicle (ECV) engine temperature gage for overheating.

1. Remove Sound Deflector from condenser fan, Sound Deflector reduces air flow over condenser in extreme heat.
2. Make sure all liners are installed in Air Beam Shelter. This creates air gap between shelter and liners.
3. Keep covers panels installed.
4. Check drive belt adjustment frequently.
5. If possible, keep CBPS under camo nets, provides some shade.
6. Keep all air intake openings clear of debris and obstructions.
7. Reference: TM 10-5410-228-10

CHEMICALLY PROTECTED DEPLOYABLE MEDICAL SYSTEM

1. Field Deployable Environmental Control System (FDECU), all air intake openings, must be kept free of any obstructions that hinder air flow. There are no other actions required for warm weather conditions.
2. Reference: TM 10-5410-283-14 & P

Approved for public release: distribution is unlimited
Distributor: U.S Training Support Center
Dec 2005